



VJ-628 CONSUMABLE PARTS REPLACEMENT LOG

Printer Serial Number _____

Printer Name (If Applicable) _____

Part	Advised Replacement	Service: Time / Date / Initials											
		Jan	Feb	Mar	Apr	May	Jun	Jul	Aug	Sep	Oct	Nov	Dec
RPRT999758 Flushing Box Sponge "Flushing Pad"	Replace every 480 hours or as needed												
RPRT991179 VJ-628 Cap Head Assembly	Replace every 2,880 hours or as needed												
RPRT999687 VJ-628 Cleaner Head Assembly "Wiper Blade"	Replace every 2,880 hours or as needed												
RPRT99VJCB Sheet Off Knife "Cutter Blade"	Replace every 1440 hours or as needed												
RPRT990050 VJ-628 Y-Rail Grease	Clean / Apply grease every 1440 hours or as needed												
Part No: RPRT994697 VJ-628 Media Holder Assembly	Replace if bent or worn												

Replacement Indicators:

- **Part No: RPRT99VJCB VJ-628 Sheet Off Knife - Cutter Blade:**
When paper shows jagged cut edges, wear or if paper dust begins to collect internally around cutting areas and capping station.
- **Part No: RPRT990050 VJ-628 Y-RAIL Grease, 4oz :**
Noisy during printing or debris builds up.
- **Part No: RPRT994697 VJ-628 Media Holder Assembly:**
Bent or Worn Part. Does not move freely from left to right of platen.
- **Part No: RPRT999758 VJ-628 Flushing Box Sponge:**
When ink stops soaking through sponge and begins to puddle or retain bubbles on surface. If sponge begins to swell above plastic retainer.

- **Part No: RPRT991179 VJ-628 Cap Head Assembly:**
Rubber seal that surrounds print head during cleaning has become worn. When area maintains ink puddle or retain bubbles on surface, indicating clog. Nozzle loss that can not be retrieved using basic cleaning measures.
- **Part No: RPRT999687 VJ-628 Cleaner Head Assembly "Wiper Blade":**
Wiper no longer makes full contact with the print head during cleanings. Wiper no longer maintains original shape and durability or shows worn edges. Wiper remains sticky with ink.